
Getting Started



TURN ON

Press and hold IQOS 3 DUO Pocket Charger Button for 4 seconds, then release; Holder Status Lights and Pocket Charger Status Lights will turn on slowly.




CHARGE HOLDER

Insert IQOS 3 DUO Holder into the IQOS 3 DUO Pocket Charger, then close door to charge.

Holder Status Light will show Holder charge level.

IQOS 3 DUO Pocket Charger*



Check Holder Status



CHECK HOLDER STATUS

Press and release the Holder Button to check status.


Holder Lights indicate IQOS 3 DUO Holder battery level.



CHECK HOLDER STATUS ON **IQOS 3 DUO** POCKET CHARGER

Press and release Pocket Charger Button to check IQOS 3 DUO Holder battery level.

IQOS 3 DUO Holder*



How to use your IQOS 3 DUO



CHECK HOLDER STATUS ON **IQOS 3** POCKET CHARGER

Press and release Pocket Charger Button to check IQOS 3 DUO Holder battery level.



1. INSERT HEATSTICK™

Insert and gently press the HeatStick to the line on filter with filter facing outside.








Charging Cable



IQOS Cleaning Sticks



2. START HEATING

Press Holder Button until IQOS 3 DUO Holder vibrates and Light(s) pulses white.



3. BEGIN USE

Start using once IQOS 3 DUO Holder vibrates twice.

CUSTOMER CARE

For the full user guide and Customer Care visit www.igos.com

CARE-PLUS

Extended support services for IQOS user

www.iqos.com/careplus**

** IQOS CARE PLUS may not be available in your country.

ENGAGE WITH IQOS

Download the IQOS Connect App on Google Play to learn more about IQOS*






*Google Play and the Google Play Logo are trademarks of Google LLC

 IQOS Connect App may not be available in your country



4. NEARLY COMPLETE


To signal the last 30 seconds or last 2 puffs, IQOS 3 DUO Holder will vibrate twice with Light(s) pulsing white.



5. REMOVE HEATSTICK™

Slide Cap upward and then remove used HeatStick.

How to clean Holder



1. USE IQOS CLEANING TOOL

Slide Cap upward and remove completely. Wait for device to cool down, insert IQOS Cleaning Tool and rotate gently.



2. USE IQOS CLEANING STICK

Insert IQOS Cleaning Stick to wipe inside of the holder. Do not touch the blade with the IQOS Cleaning Stick.


Quick Tips



CHECK POCKET CHARGER STATUS

Press and release Pocket Charger Button, to check battery level.

Lights will turn on to indicate battery status.



TO RESET

Press Pocket Charger Button until lights fade out, then release.

All Status Lights will turn OFF, blink twice, and progressively fade in, to confirm a RESET.



LIGHTS BLINK WHITE TWICE

IQOS is outside operating temperature range (0°C-50°C) or Holder needs to be inserted in Pocket Charger with door closed until it is fully charged.



LIGHT BLINKS RED

Reset IQOS 3 DUO. If red light blinking persists, contact Customer Care.